

Please follow up the below instruction to connect the original PS3 controller to Magic-S Pro on Switch , thanks !

1) Please turn on Switch and setup the “Pro Controller Wired Communication” of the Nintendo Switch system on.

(Tips: System Settings - Controllers and Sensors - Pro Controller Wired Communication – ON.)


Next put Switch handheld to Switch Dock and turn on Switch Dock , keep the LED of Switch Dock is lighting up (Green color) .



2) Plugging Magic-S Pro to Switch Dock USB slot (any of USB slot between three USB slots) .



2) Please make sure your adapter is in Switch Pro mode (The LED indicator is in **Purple**). If not in Purple mode, please switch to the **Purple** mode manually by pressing and holding the button located at the side of the adapter for 3-5 seconds.



- 4) Plugging the original PS3 controller to Magic-S Pro by using a standard USB cable , make the input works !
- 5) if the wired connection works normally , then remove the USB cable from Magic-S Pro . Press the Home button of the original PS3 controller , the input will work well !

